

ECONO-MASTER LOAD CHART

MODEL:

EM-2000	2000	1500	1000	500
EM-4000	4000	3000	2000	1000
EM-6000	6000	4500	3000	1500

