


# HUSKY-MASTER/SUPER-MASTER LOAD CHART



UNIT	MAXIMUM CAPACITY (LBS.)
HM/SM-2000	2,000
HM/SM-4000	4,000
HM/SM-6000	6,000

RANGE A	RANGE B	RANGE C
1,500	3,000	1,000
4,500	3,000	2,000
		3,000

0 12 24 36 48 60 72 84 96 108 120 132 144 156