


HUSKY-MASTER/SUPER-MASTER LOAD CHART



MAXIMUM CAPACITY (LBS.)				
UNIT	RANGE A	RANGE B	RANGE C	GN(x)
HM/SM-2000	2,000	1,500	1,000	500*
HM/SM-4000	4,000	3,000	2,000	750*
HM/SM-6000	6,000	4,500	3,000	1,000*

*HM/SM-GN(x) CAP RATED OVER 45° BOOM ANGLE

SUPER-MASTER
CAPACITY DROPS 50%
WHEN ROTATED
OUTSIDE OF LEGS